Heated Front Seats

from 2000 m.y.

Fuse Panel :

Fuse Colors :

30 A - Green
25 A - White
20 A - Yellow
15 A - Blue
10 A - Red
7.5A - Brown
5 A - Beige
3 A - Lilac

Fuse in fusebox from 23 onwards are numbered 223 onwards in Current Flow Diagram.

ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = grey
li = lilac
ge = yellow
or = orange

D - Ignition/Starter Switch
E94 - Adjuster for heated driver's seat
E95 - Adjuster for heated passenger seat
F138 - Airbag Spiral Spring/Return Spring With Slip Ring
J218 - Instrument Cluster Combination Processor
J453 - Control module for multi-function steering wheel
S5 - Fuse
S244 - Fuse in fuse holder
T5g - Wire Connector, 5-Point, behind the covering for steering wheel switch
T6r - Wire Connector, 6-Point, white, connector station, left, A-pillar
T32 - Wire Connector, 32-Point, blue, on instrument cluster

96 - Ground connection -1-, in heated seats wiring harness
135 - Ground connection -2-, in instrument panel wiring harness
A2 - plus connection (15), in instrument panel wiring harness
A19 - wire connection (58d), in instrument panel wiring harness
A40 - plus connection -1- (30), in instrument cluster wiring harness
A74 - Connector (15a - fuse 5) in instrument panel wiring harness
* - only for models with heated steering wheel and multi-function steering wheel
** - only for models with heated steering wheel

ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = grey
li = lilac
ge = yellow
or = orange

G59 - Driver's Heated Seat Temperature Sensor
J218 - Instrument Cluster Combination Processor
T2a - Wire Connector, double, under driver's seat
T6r - Wire Connector, 6-Point, white, connector station, left, A-pillar
T6t - Wire Connector, 6-Point, green, under driver's seat
T6af - Wire Connector, 6-Point, red, under driver's seat
T32a - Wire Connector, 32-Point, green, on instrument cluster
Z6 - Driver's Seat Heating Element
Z7 - Driver's Backrest Heating Element
Z31 - Driver's Seat Side Bolster Heater

32 - Ground connection, behind instrument panel, left
96 - Ground connection -1-, in heated seats wiring harness

ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = grey
li = lilac
ge = yellow
or = orange

G60 - Passenger's Heated Seat Temperature Sensor
T2o - Wire Connector, double, in passenger seat
T6s - Wire Connector, 6-Point, green, under passenger seat
Z8 - Passenger's Seat Heating Element
Z9 - Passenger's Backrest Heating Element
Z33 - Passenger's Seat Side Bolster Heater

96 - Ground connection -1-, in heated seats wiring harness