10-Way Power Front Seats (w/o memory)

from 2000 m.y.

Fuse Panel :

Fuse Colors :

30 A - Green
25 A - White
20 A - Yellow
15 A - Blue
10 A - Red
7.5A - Brown
5 A - Beige
3 A - Lilac

Fuse in fusebox from 23 onwards are numbered 223 onwards in Current Flow Diagram.

8-way Relay Carrier :

Fuse Location :

15 - Power (Memory) Seat Circuit Breaker

16 - Power Seat Circuit Breaker

ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = grey
li = lilac
ge = yellow
or = orange

E61 - Driver's Seat Fore/Aft and Height Adjusting Switch
E62 - Driver's Seat Front Height Adjusting Switch
E63 - Driver's Seat Rear Height Adjusting Switch
E96 - Driver's Backrest Adjustment Switch
S44 - Power (Memory) Seat Circuit Breaker
T6af - Wire Connector, 6-Point, red, under driver's seat
V28 - Driver's seat fore/aft adjusting motor
V29 - Motor for front height adjustment, driver seat
V30 - Motor for rear height adjustment, driver seat
V45 - Motor for seatback adjustment, driver seat

44 - Ground connection, on left A-pillar, lower part
501 - Threaded connection -2- (30) on the relay plate

ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = grey
li = lilac
ge = yellow
or = orange

E176 - Driver's seat lumbar support adjustment switch
E177 - Front passenger seat lumbar support adjustment switch
V125 - Driver's seat lumbar support curvature adjustment motor
V126 - Front passenger seat lumbar support curvature adjustment motor
V126 - Driver's seat and Front passenger seat lumbar support curvature adjustment

ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = grey
li = lilac
ge = yellow
or = orange

E64 - Passenger's Seat Fore/Aft Adjusting Switch
E65 - Passenger's Seat Front Height Adjusting Switch
E66 - Passenger's Seat Rear Height Adjusting Switch
E98 - Passenger Backrest Adjustment Switch
S80 - Power Seat Circuit Breaker
T6ag - Wire Connector, 6-Point, red, under passenger seat
V31 - Passenger's Seat Fore/Aft Adjusting Motor
V32 - Passenger's Seat Front Height Adjusting Motor
V33 - Passenger's Seat Rear Height Adjusting Motor
V46 - Passenger's Backrest Adjusting Motor

501 - Threaded connection -2- (30) on the relay plate

44 - Ground connection, on left A-pillar, lower part