Airbag Control Module

1999 m. y.

Fuse Panel :

Fuse Colors :

30 A – Green
25 A – White
20 A – Yellow
15 A – Blue
10 A – Red

Fuse in fusebox from 23 onwards are numbered 223 onwards in Current Flow Diagram.

ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = grey
li = violet
ge = yellow

E3 – Emergency Flasher Switch
F138 – Airbag Spiral Spring / Return Spring With Slip Ring
J234 – Airbag Control Module
N95 – Driver's Side Airbag Igniter
N131 – Passenger's Side Airbag Igniter 1
N199 – Ignitor for side airbag, driver's side
N200 – Ignitor for side airbag, passenger's side
T2s – Wire Connector, double, yellow, connector station left, A–pillar
T2t – Wire Connector, double, yellow, connector station right, A–pillar
T3e – Wire Connector, 3 Point, behind instrument panel, center
T4q – Wire Connector, 4 Point, yellow, below passenger's seat
T4r – Wire Connector, 4 Point, yellow, below driver's seat
T5g – Wire Connector, 5 Point, behind steering column switch cover
T5h – Wire Connector, 5 Point, behind steering column switch cover
T10an – Wire Connector, 10 Point, yellow, connector station right, A–pillar
32 – Ground connection, behind instrument panel, left
109 – Ground connection, in airbag wiring harness
A125 – Connector (Crash–signal), in instrument panel wiring harness
– Bridge closes when disconnecting connector (safety feature)

ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = grey
li = violet
ge = yellow

- G179 - Crash sensor für side airbag, driver‘s side
- G180 - Crash sensor für side airbag, passenger‘s side
- J218 - Instrument Cluster Combination Processor
- J234 - Airbag Control Module
- K75 - Airbag Malfunction Indicator Lamp (MIL)
- N153 - Left Seat Belt Tensioner Igniter
- N154 - Right Seat Belt Tensioner Igniter
- T2u - Wire Connector, double, connector station left, B-pillar
- T2v - Wire Connector, double, connector station right, B-pillar
- T10an - Wire Connector, 10 Point, yellow, connector station right, A-pillar
- T32 - Wire Connector, 32 Point, blue, on instrument cluster
- T32a - Wire Connector, 32 Point, green, on instrument cluster

- 109 - Ground connection, in airbag wiring harness
- A76 - Connector (K-diagnosis wire), in instrument panel wiring harness
- Bridge closes when disconnecting connector (safety feature)
- * - Up to 8/99
- ** - From 8/99

ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = grey
li = violet
ge = yellow

D - Ignition/Starter Switch
J234 - Airbag Control Module
N196 - Igniter for belt tensioner rear, driver's side
N197 - Igniter for belt tensioner rear, passenger's side
N198 - Igniter for belt tensioner rear, center
N251 - Igniter for headairbag, driver's side
N252 - Igniter for headairbag, passenger's side
T2y - Wire Connector, double, green, below rear seat, right
T2z - Wire Connector, double, yellow, below rear seat, center
T2ac - Wire Connector, double, blue, below rear seat, left
T4s - Wire Connector, 4 Point, yellow, below driver's seat
T4t - Wire Connector, 4 Point, yellow, below passenger's seat
T10an - Wire Connector, 10 Point, yellow, connector station right, A-pillar

109 - Ground connection, in airbag wiring harness
A2 - Plus connection (15), in instrument panel wiring harness
* - Headairbag Only
** - Audi Avant Only
- Bridge closes when disconnecting connector (safety feature)