Navigation

2000 m. y.

Fuse Panel :

Fuse Colors :

30 A - Green
25 A - White
20 A - Yellow
15 A - Blue
10 A - Red

Fuse in fusebox from 23 onwards are numbered 223 onwards in Current Flow Diagram.

ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = grey
li = violet
ge = yellow

D - Ignition/Starter Switch
J401 - Control module for navigation with CD-mechanism
R - Radio
R36 - Telephone Transceiver
R50 - Antenna for Navigation System (GPS)
S5 - Fuse in fuse holder
T3az - Wire Connector, 3 Point, red, behind instrument panel, left
T8i - Wire Connector, 8 Point, black, on Control module for navigation
T10af - Wire Connector, 10 Point, red, on Radio
T15n - Wire Connector, 15 Point, brown, in console
T15p - Wire Connector, 15 Point, red, behind instrument panel, left
T20c - Wire Connector, 20 Point, black, on Control module for navigation

135 - Ground connection -2-, in instrument panel wiring harness
A2 - Plus connection (15), in instrument panel wiring harness
A50 - Plus connection (30as), in instrument panel wiring harness
A74 - Connector (15a, fuse 5), in instrument panel wiring harness
A129 - Connection (quiet switch), in instrument panel wiring harness

ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = grey
li = violet
ge = yellow

E272 - Board Computer Function Selector Switch II
J189 - Auto Check System
J218 - Instrument Cluster Combination Processor
J401 - Control module for navigation with CD-mechanism
M16 - Left Back-up Light
M17 - Right Back-up Light
T8i - Wire Connector, 8 Point, black, on Control module for navigation
T15p - Wire Connector, 15 Point, red, behind instrument panel, left
T20c - Wire Connector, 20 Point, black, on Control module for navigation
T32 - Wire Connector, 32 Point, blue, on intrument cluster
T32a - Wire Connector, 32 Point, green, on intrument cluster
T32b - Wire Connector, 32 Point, grey, on intrument cluster

199 - Ground connection -3-, in instrument panel wiring harness
A19 - Wire connection (58d), in instrument panel wiring harness
A60 - Wire connection (Vehicle speed signal), in instrument panel wiring harness
A76 - Connector (K-diagosis wire), in instrument panel wiring harness
A87 - Connector (reverse lamp), in instrument panel wiring harness
B229 - Connection (High-Bus) (interior wiring harness)
B230 - Connection (Low-Bus) (interior wiring harness)