Driver's Information System

2000 m. y.

Fuse Panel :

Fuse Colors :

30 A - Green
25 A - White
20 A - Yellow
15 A - Blue
10 A - Red

Fuse in fusebox from 23 onwards are numbered 223 onwards in Current Flow Diagram.

13-way Relay Carrier :

Relay Location :

4 - Rear Lamp Control Module
5 - Rear Lamp Control Module

ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = grey
li = violet
ge = yellow

F10 - Left Rear Door Contact Switch
F11 - Right Rear Door Contact Switch
J189 - Auto Check System
J218 - Instrument Cluster Combination Processor
J220 - Motronic Engine Control Module (ECM)
R - Radio
T10 - Wire Connector, 10 Point, brown, connector station, on electronics box in plenum chamber
T10i - Wire Connector, 10 Point, black, in center console
T15a - Wire Connector, 15 Point, black, connector station right, A-pillar
T20b - Wire Connector, 20 Point, black, on Radio
T32 - Wire Connector, 32 Point, blue, on instrument cluster
T32a - Wire Connector, 32 Point, green, on instrument cluster
T32b - Wire Connector, 32 Point, grey, on instrument cluster

V94 - Central Locking/Alarm System/Interior Light Delay Control Module

199 - Ground connection -3-, in instrument panel wiring harness
A117 - Connector (Enable), in instrument panel wiring harness
A118 - Connector (Data), in instrument panel wiring harness
A119 - Connector (Clock), in instrument panel wiring harness

* - See wiring diagram for Central Locking and Anti-Theft System with Interior Monitoring Sensors

ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = grey
li = violet
ge = yellow

D - Ignition / Starter Switch
E91 - Trip Computer Function Selector Switch
E92 - Trip Computer Reset Button
F3 - Door contact switch - passenger side
F77 - Windshield Washer Fluid Level Warning Switch
J124 - Rear Lamp Control Module
J189 - Auto Check System
S5 - Fuse in fuse holder
T10ad - Wire Connector, 10 Point, red, connector station left, A-pillar
T10ae - Wire Connector, 10 Point, pink, connector station left, A-pillar
T15a - Wire Connector, 15 Point, black, connector station right, A-pillar
T15b - Wire Connector, 15 Point, brown, connector station right, A-pillar
T15c - Wire Connector, 15 Point, brown, connector station left, A-pillar
T32b - Wire Connector, 32 Point, grey, on instrument cluster
135 - Ground connection -2-, in instrument panel wiring harness
199 - Ground connection -3-, in instrument panel wiring harness
A2 - Plus connection (15), in instrument panel wiring harness
A74 - Connector (15a - fuse 5), in instrument panel wiring harness
Q52 - Wire Connection (door contact switch), in alarm system wiring harness
* - See wiring diagram for Navigation

ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = grey
li = violet
ge = yellow

J124 - Rear Lamp Control Module
L1 - Left Headlight
L2 - Right Headlight
M2 - Right Tail Light
M4 - Left Tail Light
M9 - Left Brake Light
M10 - Right Brake Light
T6 - Wire Connector, 6 Point, yellow, connector station right, A-pillar
T6e - Wire Connector, 6 Point, blue, connector station left, A-pillar
T8g - Wire Connector, 8 Point, near headlight, right
T8h - Wire Connector, 8 Point, near headlight, left
T10a - Wire Connector, 10 Point, brown, connector station right, A-pillar
T10ae - Wire Connector, 10 Point, pink, connector station left, A-pillar
V48 - Left Headlight Beam Adjusting Motor
V49 - Right Headlight Beam Adjusting Motor

86 - Ground connection -1-, in rear wiring harness
176 - Ground connection, in right headlight wiring harness
179 - Ground connection, in left headlight wiring harness
196 - Ground connection -3-, in rear wiring harness

* - Sedan Only
** - Avant Only
*** - 2.7l-Injection Engine Only

ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = grey
li = violet
ge = yellow

E4 - Headlight Dimmer / Flasher Switch
E19 - Park Light Switch
F - Brake Light Switch
J124 - Rear Lamp Control Module
M1 - Left Parking Light
M3 - Right Parking Light
M25 - High-mount Brake Light
T3s - Wire Connector, 3 Point, white, near headlight, left
T3t - Wire Connector, 3 Point, white, near headlight, right
T6 - Wire Connector, 6 Point, yellow, connector station right, A-pillar
T8e - Wire Connector, 8 Point, black, in luggage compartment, left rear
T10ae - Wire Connector, 10 Point, pink, connector station left, A-pillar
T10ao - Wire Connector, 10 Point, white, connector station left, A-pillar

86 - Ground connection -1-, in rear wiring harness
218 - Ground connection -1-, in rear lid wiring harness
A9 - Plus connection (56b), in instrument panel wiring harness
A18 - Wire connection (54), in instrument panel wiring harness
A32 - Plus connection (30), in instrument panel wiring harness
A43 - Wire connection (57l), in instrument panel wiring harness
A44 - Wire connection (57r), in instrument panel wiring harness

* - Sedan Only
** - Avant Only