Heated Door Locks

1996 m. y.

Fuse Panel :

Fuse Colors :

30 A – Green
25 A – White
20 A – Yellow
15 A – Blue
10 A – Red

Fuse in fusebox from 23 onwards are numbered 223 onwards in Current Flow Diagram.

ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = grey
li = violet
ge = yellow

E125 – Left Heated Door Lock Switch
J210 – Left Heated Door Lock Control Module
S17 – Fuse in fuse holder
T2 – Wire Connector, double, black, connector station left, A–pillar
Z22 – Left Door Lock Heater

135 – Ground connection –2–, in instrument panel wiring harness
A40 – Plus connection –1– (30), in instrument panel wiring harness
A98 – Plus connection –4– (30), in instrument panel wiring harness

* – From 8/97
** – Up To 8/97