Adjustable and Heated Power Mirrors

1999 m. y.

Fuse Panel :

Fuse Colors :

30 A – Green
25 A – White
20 A – Yellow
15 A – Blue
10 A – Red

Fuse in fusebox from 23 onwards are numbered 223 onwards in Current Flow Diagram.

ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = grey
li = violet
ge = yellow

D – Ignition / Starter Switch
E43 – Mirror Adjustment Switch
S5 – Fuse in fuse holder
S9 – Fuse in fuse holder
T10d – Wire Connector, 10 Point, black, connector station left, A–pillar
T10e – Wire Connector, 10 Point, black, connector station right, A–pillar
V17 – Driver's Side Mirror Adjustment Motor
V25 – Passenger's Side Mirror Adjustment Motor
Z4 – Driver's Side Heated Mirrior
Z5 – Passenger's Side Heated Mirrior

135 – Ground connection –2–, in instrument panel wiring harness
A2 – Plus connection (15), in instrument panel wiring harness
A34 – Wire connection (75x), in instrument panel wiring harness
A74 – Connector (15a – fuse 5), in instrument panel wiring harness